

ENOTE 0027

Updating Bios on a Working FieldServer

TABLE OF CONTENTS

1	Introduction	2
2	Procedure:.....	2

1 INTRODUCTION

This procedure requires sending files to the FieldServer. Please refer to Enote0026 for detailed instructions on sending files.

The BIOS update is supplied as a “.bin” file (e.g. IC28.Bin)

2 PROCEDURE:

1. Create a BAT file called Trojan.Bat
2. In the Trojan.bat file, type `ezrom -w <bin filename>` (e.g. `ezrom -w IC28.Bin`)
3. Save the BAT file
4. Open Ruinet.
5. Send Trojan.bat and the Bin file to the FieldServer. (See Enote 0026)
6. Once both files are successfully sent, cycle power to the FieldServer.
7. Wait 10 minutes for the BIOS upgrade to complete.
8. Cycle power to the FieldServer again.
9. The BIOS should now be upgraded

Note: It is very important the step 7 completes without any interruptions, or else the FieldServer might be corrupted and will only be recoverable by returning to the FieldServer offices.