

Plant TV Installation

On SCADA node machine (existing machine)

- the nodename is “GASSENS” make sure the MS networking is setup so that machine name = “GASSENS”
- Note: GASSENS is the node name which is used as an Example. Node name and the machine name should MATCH.
- Share the FIX32 directory
- reboot if necessary
- Open Fix System config util
- in Configure Networking enable Network Support
 - Press advanced, Enable TCP/IP, Disable Netbios
- Save & startup fix

On New Plant TV machine (Same as View node)

- Open DOS box & type
PING GASSENS<enter>
If this does not work, read up on MS networking do not bother to proceed to next until working
- Open Explorer and create a Network drive mapping to
[\\GASSENS\FIX32](#) >> F:
- Install fix, with plant TV option disk if supplied
- Open Fix System config util
- Disable SCADA Support
- in Configure Networking enable Network Support
 - Press advanced, Enable TCP/IP, Disable Netbios
 - Add “GASSENS” to configured remote node
- in configure paths
set picture path to F:\PIC (the drive mapping)
- Save & Startup fix